


## For Residential Use Only

Please visit our website for the most current instructions, assembly tips, report damage, or request parts.

# WE Time to get started

Set up a clean and soft workplace to avoid damage during assembly. You can use the box and internal protections as a cover. It also helps to double-check if you have got all the pieces and parts before diving into the assembly.



**Estimated time  
for assembly**



2 People Build

**People recommended  
for assembly**

Make it a team effort!  
Grab a friend for quicker,  
easier assembly.

## Tools Needed


Grab a Phillips screwdriver to  
conquer this assembly



## Use power tools with caution

This furniture is made of Solid Wood and Composite Wood, soft materials. If you choose to use power tools, set it to the slower setting. Be careful! Power tools can cause cracking or damage to the furniture, they can also damage the hardware if misused.

Power tool damages are not covered by the Walker Edison warranty.











**Scan to get assembly tips and help!**



# Parts List

Part Number	Description	Quantity
01	Bottom Panel	1
02	Left Panel	1
03	Top Panel	1
04	Right Panel	1
05	Door	2
06	Glass Door Front	2
07	Foot	5
08	Back Panel	1
09	Rail	1




Part	Size	Name	Quantity
A 	8x30mm	Wooden dowel	12
B 	Ø7x30mm	Cam Bolt	8
C 	Ø15x10mm	Cam Lock	8
D 	Ø3.5x12mm	Screw	16
E 	Ø3.5x25mm	Screw	4
F 	Ø4x14mm	Screw	24
G 	Ø4x20mm	Screw	5
H 	Ø5x40mm	Screw	5
I 	Ø3x16mm	Screw	4
J 	Ø 19mm	Sticker	16
K 	14.7x30mm	Support	4
L 	224mm	Handle	2
M 	Ø35mm	Metal Hinge	4
N 	25x12mm	Door Latch	16
O 	1/4x5/8	Washer	02
P 	20x200mm	Wall Anchor	01

*The hardware quantities listed above are required for proper assembly.  
Extra hardware pieces may be included.*

# Step 1


Let's get started! Insert Wooden Dowels (A) into Bottom Panel (1), Left Panel (2), Right Panel (4) and Rail (9). Also, attach Cam Bolts (B) to Left Panel (2), Top Panel (3) and Right Panel (4) using a Phillips screwdriver.




## Wooden Dowels

Dowels are essential in furniture assembly to create strong, precise connections. They ensure structural integrity, prevent shifting, and simplify alignment, resulting in sturdier, longer-lasting furniture.



Follow these steps:



1: Select the appropriate size dowel according with step.





2: Insert into drilled hole and press firmly to ensure placement is set.




3: Align the dowel with corresponding piece and press together until secure.

# Step 2

Attach Hinges (M) to Doors (5) using Screw (F) and a Phillips screwdriver. Insert Glass Door Front (6) in Doors (5) and secure using Door Latch (N), Screw (D) and a Phillips screwdriver.





To keep your product looking its best and scratch-free, try assembling it on a soft surface like carpet or a blanket. This helps prevent any accidental scratches and keeps your furniture in top shape!




# Step 3

Join Bottom Panel (1) and Left Panel (2) using Cam Locks (C) and a Phillips screwdriver.




## Cam Locks


Cam Locks help to securely join two pieces together.  
Follow these easy steps:



1: Insert Cam Bolt into bolt holes on the flat side. Don't over tighten!



2: Assemble both parts together. The cam bolts go in the drill holes that have a circular hole on the side, you should be able to see the cam bolts through it. After fitting parts together insert the cam lock on the side holes.




3: On the back of the Cam Lock will be a "C" shape. Insert the Cam Lock so the opening of the "C" fits over the Cam Bolt. Tighten with the screwdriver.

# Step 4




Secure Rail (9) and Right Panel (4) using dowels, Cam Locks (C) and a Phillips screwdriver.



# Step 5




Slide Back Panel (8) between the grooves on Left Panel (2) and Right Panel (4) fitting in Bottom Panel (1).



# Step 6





Attach Top Panel (3) to Left Panel (2) and Right Panel (4) using Cam Locks (C) and a Phillips screwdriver.




# Step 7




Attach Door (5) on Left Panel (2) using Screws (F) and a Phillips screwdriver.




## Adjusting The Cabinet Doors



Adjust horizontal width with this screw



Adjust depth position by loosening the hinge arm mounting screw




Adjust vertical height via the screws in the mounting plate

# Step 8





Secure Handle (L) using Screw (E) and a Phillips screwdriver.



# Step 9




Attach Door (5) on Right Panel (4) using Screws (F) and a Phillips screwdriver.




Tip


## Adjusting The Cabinet Doors



Adjust horizontal width  
with this screw




Adjust depth position  
by loosening the hinge  
arm mounting screw



Adjust vertical height  
via the screws in the  
mounting plate




# Step 10

Repeat Step 8.




# Step 11

Secure Back Panel (8) using Support (K), Screw (I) and a Phillips screwdriver.




# Step 12

If you are not using your new cabinet on top of other Modular Mia Cabinet, you can attach Feet (7) using Screw (H) and a Phillips screwdriver.




## Modular Assembly Options

### Step 13




### Step 14





# Step 13

If attaching cabinets side by side, use Screws (G) and a Phillips screwdriver to join them through the side panels. The holes are predrilled.





## Assembly Option




# Step 14

If assembling your cabinets on top of each other, use Screws (G) and a Phillips screwdriver to join them through the top and bottom panels. The holes are predrilled.




## Assembly Option




# Step 15

With everything in place use Stickers (J) to cover the extra holes.




# Step 16

Attach your Cabinet to the wall. Secure Wall Anchor (P) to your cabinet using Washer (O), Screw (G) and a Phillips screwdriver.



# Step 17


To finish this up use a plastic bush suitable for your wall. Then, secure the Wall anchor (L) to the wall using Washer (M) and a screw also suitable for your wall.



## Warning

Serious or fatal injuries can occur from furniture tipping over. To prevent the furniture from tipping over, we recommend that it is permanently attached to the wall. Wall anchor is included in this product. Please make sure the extra hardware is suitable for your walls before installing, as different wall materials may require different types of anchors.

# You did it! Enjoy your new Modular Cabinet with Glass Door!



**Congratulations on your new piece of furniture!**

We would love to hear about it and see it.  
Please leave us a review or post a picture with


# Assembling furniture can be tricky sometimes.

Our customer service team, located in Utah, is here for product information, help assembling a product, or for any other customer support issue

Visit our Customer Service website at

We are available to help Monday -Thursday 8am-5pm, Friday 8am-3pm MST

For details on Assembly Videos, Assembly Instructions, Replacement Parts, and Customer service,  
**SCAN HERE**



For cleaning, never use abrasives, use a soft cloth and water with neutral soap to clean the furniture.